CABINET PARTS

REFRIGERATOR

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A Serviceable Part)
2	2174690	Hinge (Top)
3	2166108	Roller−Front (2)
4	489426	Screw
5	489385	Clamp, Tube (Water Supply Line)
6	489459	Screw
7	2174650	Screw
8	2172745	Shim, Bottom Hinge
12	549193	Clamp−Cord
15	489423	Screw
16	2183066	Hinge, Center
17	2163757	Shim, Hinge Center
18	489463	Screw
20	2179810	Hinge Butt
24		Fitting, Water Tube (NOT SERVICED)
27		Hole Plug (6)
	2151652	White
	2151653	Almond
31	2166251	Cover, Valve
35		Corner Filler (2)
	2163733	White
	2166187	Almond
36		Grille
	2182429	White
	2182430	Almond
37	489341	Washer, Plain
38	487576	Washer, Nylon
39	2176201	Shim
40		Cover−Hinge
	2172613	White
	2176204	Almond
41		Rail, Center (NOT SERVICED)
42		Corner Filler, Grille
	2166156	White
	2166204	Almond
43	2183063	Pin, Hinge
44	2183158	Cover, Unit

LINER PARTS

For Models: ET19PKXEW01, ET19PKXEN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2166181	Gasket, Evaporator Cover (Side)
4	2183400	Timer, Defrost
5	549512	Thermostat Tube Barrier
6	940014	Hole Plug
7	2172542	Wire Assy. Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2176298	Fan Motor
11	2163777	Fan Blade
12	2179790	Control Box
13	2193034	Thermostat Assembly (Includes Items 5, 18, & 36)
14	2176341	Clip, Defrost Timer
15	489412	Screw
16	2183154	Cover−Evaporator
17	946059	Light Bulb (2)
18	2163802	Weight, Thermal
19	1118894	Rocker Arm Switch
20	2179823	Wire Assembly, Freezer Compartment
21	2176281	Cover, Air Diffuser
22	2176296	Knob, Thermostat
23	2182340	Air Tower
24	2176280	Air Diffuser, Bottom
25	2172565	Freezer Floor
26	2179877	Air Diffuser, Top (Includes Item 37)
27	2183038	Cover, Hole
28	941839	Hole Plug
29	2163827	Bracket, Fan Motor
30	2166178	Gasket, Evaporator Cover (Top)
31	2174629	Air Return & Foil Assembly
32	487996	Cap
33	489438	Screw
34	2176297	Knob, Damper
36	2172532	Seal, Rear Thermostat
37	2179859	Post, Damper
38	2171931	Valve, Release
44	2163810	Bracket, Damper Knob

SHELF PARTS

For Models: ET19PKXEW01, ET19PKXEN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	2163756	Shelf, Ladder (2)
2	2163826	Shelf, Ladder Center
3	2163762	Cup, Shelf Mounting
4	2169933	Egg Bin
5	520965	Screw
6	2190651	Glass, Full Shelf
7	2174446	Frame Assembly, Shelf
8	2163862	Shelf, Full Cantilever
9	2190580	Crisper Cover
10	2163884	Trim, Shelf Rear
11	2176233	Glass, Crisper Cover
12	2179716	Frame Assembly, Meat Shelf
15	2172541	Crisper, Support
16	2184417	Shelf Assembly, Spillguard
17	2176275	Shelf, Freezer
19	2190601	Pan, Crisper Wide
20	2176231	Pan, Meat
23	1116917	Container
33	2163835	Crisper Track, Center
34	2190599	Pan, Crisper
45	2184419	Shelf Assembly, Spillguard
46	841180	Ice Cube Tray

REFRIGERATOR DOOR PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Panel, Refrigerator Door (Includes Item 8)
	2171245	White
	2171246	Almond
3	2183141	End Cap
4		Bracket, Door Stop
	2159368	White And Almond Models
5	488921	Screw, 8 x 1/2
6	489028	Screw, 8−15 x 1/2
7		Hole Plug
	844478	White
	989196	Almond
8		Door Gasket, Magnetic
	2159057	Mist Beige
9	943188	Shim, Handle
10	9791771	End Cap, Handle
11	2156062	Housing Compartment
13	2159302	Tray, Door
16	489006	Screw
17	487909	Screw
19		Handle
	2148035	White
	2148036	Almond
20	2190632	Bin, Door Shelf (3)
21	2177260	Trim, Door Shelf
22	2182400	Door Compartment
23	2159312	Trim−Door Shelf
24		Hole Plug, Handle
	1122653	White
	1122654	Almond
27		Cover, Screw
	9791769	White
	9791770	Almond
38	2177340	Endcap, Door Trim
39	2159300	Plug−Trim

UNIT PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	2182437	Plate, Unit Mounting
2	2182380	Defrost Bimetal
3	2179882	Condenser
4	2176300	Heater, Defrost
5	2176337	Evaporator Assy.
6	489414	Screw
7	2172619	Drain Pan
8	2176301	Bracket, Heater
9	489242	Screw
10	2163780	Extension, Air Baffle
11	2169464	Clamp (Production Only)
12	2162358	Cover (Service Only)
13		Overload
	2149959	(Production Comp.)
	2154759	(Service Comp.)
14		Grommet (4)
	2183042	Production
	1100826	Service
15	2169337	Module
17	2163782	Roller (2)
18	2179826	Rivet
19	2182338	Clip, Heater
20	489473	Screw
28	2176660	Compressor (Includes Items 11, 12, 13, 29, 32, 38 & 56) (Also Order 482801 Installation Kit & 876765 Tube Kit)
29	2174865	Drier
30	2155774	Clamp
32	2169137	Capacitor
38	2172890	Wire Assembly
39	2182395	Air Baffle
40	2176336	Motor, Condenser
42	2184584	Wire Assy. Unit
43	851732	Fan Blade
44	486692	Nut
46	2179722	Tube, Discharge
47	2184550	Tube, Suction
48	2184551	Tube, Process
49	2174670	Tube, Condenser To Heat Loop
56	487240	Screw
58	2163795	Evap. Tray

Following Parts Not Illustrated and Optional Parts Not Included

Part No.	DESCRIPTION
978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")
482278	Start Kit

REFRIGERANT CHARGE

4.0 Ozs.
(R134A)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Panel, Freezer Door (Includes Item 8)
	2171232	White
	2171234	Almond
4	2159367	Bracket, Door Stop
5	488921	Screw
6	489028	Screw, 8−15 x 1/2
7		Hole Plug
	844478	White
	989196	Almond
8		Door Gasket, Magnetic
	2159327	Mist Beige
9	991259	Tape
10		Nameplate
	2162781	White
	2162782	Almond
13	9791776	Handle End
14	943188	Shim, Handle
15	9791771	End Cap, Handle
16	489006	Screw
17	2171282	Trim, Door Shelf (2)
19		Handle
	2171043	White
	2171044	Almond
21	943187	Shim
22	2156002	EndCap, Trim (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LITERATURE AND OPTIONAL PARTS

For Models: ET19PKXEW01, ET19PKXEN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Miscellaneous

978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4" x 108")
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
505587	Sealer, Mastic (1 Qt.)
511873	Touch−Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
606755	Bag, Insulation (36−5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
799832	Kit, Porcelain Repair (White)
503695	Cork Sealer (1/4 Pound)
2176379	Door Reversal Instructions

Customer Touch−Up Material

*350942	Primer, White (13 Oz. Spray Can)
*350939	Enamel, Black (13 Oz. Spray Can)
*350930	Enamel, White (13 Oz. Spray Can)
*350956	Enamel, Almond (13 Oz. Spray Can)
72017	Brush Touch−Up Kit (White)
72032	Brush Touch−Up Kit (Black)
72107	Brush Touch−Up Kit (Almond)

Refinishing Material

799344	Enamel, White (1 Qt. Uncut)
978883	Enamel, Almond (1 Qt. Uncut)
833938	Kit, Terminal Connector

* not to be used where the paint may make contact with the door gaskets.

LITERATURE PARTS

LIT2172667	Service & Wiring Sheet
LIT2184515	Energy Label
LIT2184593	Use & Care Guide

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

LIT677969	Do−It−Yourself Manual Ref./Fzr.
LIT677971	Do−It−Yourself Manual, Icemaker

ICE MAKER FIELD INSTALLABLE

ECKMF94

TORX SCREW WRENCH

1117510	Torx Key